

Sizing Guide



This guide will assist in selecting the correct respirator size for your face. Begin with measuring the vertical line as shown to determine the dimension between the nose-bridge area to the chin.

Vertical Line Measurement

100, 300 & 400's series Comfort-Air® Reusable Respirators





100 Series Silicone Mask Sizes: S, M, L



300 Series Thermoplastic Mask Sizes: S/M, M/L




400 Series Elastomeric Mask Sizes: S/M, M/L

Once you determine the vertical dimension, measure the horizontal line. In order to obtain a proper fit and airtight seal, your measurements cannot be greater than the dimensions shown below. Refer to images below of interior of the Comfort-Air® respirators.



100S – Silicone half mask size small Vertical Line - 3 %s "Horizontal Line - 4 "



100M - Silicone half mask size medium Vertical Line - 4.75 " Horizontal Line - 4 "



100L - Silicone half mask size large Vertical Line - 4.75 " Horizontal Line - 4.25 "









300SM - Thermoplastic half mask size small/medium 400SM - Elastomeric half mask size small/medium Vertical Line - 3 ¾ " Horizontal Line - 4.55 "

300ML - Thermoplastic half mask size medium/ large 400ML - Elastomeric half mask size medium/ large Vertical Line - 4.5 " Horizontal Line - 3 ¾ "